

GAGEWOVEN®

ARCHITECTURAL WIRE MESH

Installation With Backer and J-Trim

- Tac weld screws onto the back of the opaque GageWoven panel.
- Countersink pockets and drill holes on the back of the MDF backer that correspond to the placement of the tac welded screws.
- Secure mesh panel onto the MDF backer using nuts threaded onto the screw ends showing through the countersunk pockets.
- Depending on size of panel, mesh may need to be secured in multiple areas. Recommended securing at every two (2) feet to ensure the center panel does not droop or sag.



Images are enlarged to show detail.

